



NOTES:

1. METAL SCUPPER BOX MUST HAVE CONTINUOUS SIDES, METAL FLANGE MUST BE CONTINUOUS WITH ROUND CORNERS.
2. WATER CUT-OFF MASTIC MUST BE HELD UNDER CONSTANT COMPRESSION.
3. METAL SCUPPER FLANGE ON WALL MUST BE TOTALLY COVERED BY UNCURED ELASTOFORM FLASHING.
4. UNCURED ELASTOFORM FLASHING MUST OVERLAP WALL FLASHING 3" (8cm) MIN.
5. A MIN. 2" (5cm) FLASHING SPLICE IS REQUIRED PAST THE NAIL HEAD ON THE METAL FLANGE OF THE SCUPPER.

- SURE-SEAL BONDING ADHESIVE
- SURE-SEAL/BRITE-PLY UNCURED ELASTOFORM FLASHING OR PRESSURE-SENSITIVE UNCURED FLASHING (IN CONJUNCTION WITH PRIMER)
- SURE-SEAL WATER CUT-OFF MASTIC.
- SURE-SEAL LAP-SEALANT
- CCW-711-90 OR CCW-UNCURED NEOPRENE FLASHING.
- METAL FLASHING (BY OTHERS)
- CCW-201 SEALANT
- SURE-SEAL H.P. PROTECTIVE MAT
- RIGID INSULATION
- CCW MIRADRAIN DRAINAGE COMPOSITE
- CCW-PROTECTION BOARD H OR HS
- CCW-500 AT 125 MILS
- CCW-500 REINFORCING FABRIC
- CCW-500 AT 90 MILS
- CCW-PRIMER OR CCW-CONTACT ADHESIVE

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

500-18A

# OVERFLOW METAL SCUPPER

